



### Installation guide "Beach closed sign" for Jaws pinball (all models)

1. Pull playfield out to where rubber stoppers are resting on front edge of cabinet.
2. Choose a where you want to install the shield. A common place e.g. is on top of the plastic above the upper right flipper.
3. Unscrew the hex nut and place the bracket with the round hole onto the screw sticking out.



4. Lock the hex nut again onto the screw. Do not overtighten
5. Peel off the protective layer of the pole and attach the sign in the angle you want it (straight or lopsided)
6. Push the pole into the square hole of the bracket. Give it a little force, as it is tight in order to hold the pole safely



7. You're done

